
HOLTKÖTTER®

The Ultimate Lighting Machines™

205 Hardman Avenue South, South Saint Paul, MN 55075
Voice: (800) 899-5444 • Fax: (888) 552-8661
e-mail: customerservice@holtkoetter.com
www.holtkoetter.com

**IT IS FIRMLY RECOMMENDED THAT A LICENSED ELECTRICIAN
INSTALL THIS FIXTURE.**

Installation

1. Remove the universal crossbar strap from the back of the sconce.
2. Connect the wires from the sconce with the wires in the outlet box according to generally accepted electrical standards.
3. Mount the crossbar strap to the outlet box after making the wire connections.
4. Mount the fixture to the crossbar strap.

Assemble the Sconce

Install the shade:

5. Unscrew the metal ring located on the socket of the lamp.
6. Place the shade over the center stem.
7. Screw the metal ring back into place, tighten hand-tight.
8. Install the bulb of your choice (not included).
Maximum Wattage: 75 Watts, Medium Edison Base.
9. Your lamp is now operational.

ASSEMBLY INSTRUCTIONS FOR

Swing-Arm Wall Sconce No. 8164



Care Instructions

Use only a soft, dry cloth to clean. If necessary, a slightly damp, soft cloth can be used to spot clean. Do not use common household cleaners on lamps or fixtures, as the lacquer on the outside of the brass may be damaged as a result. Enjoy your new Holtkötter lamp.