

# Shade Installation Instructions

C48

Moreau Floor Lamps 23-3070, 23-3070C & Moreau Tall Table Lamps 27-3077, 27-3077C

## To Install Shade (Figures 1-2)

### Component Parts

A Turn Knob	E Harp
B Harp Holder	F Finial
C Socket	G Shade
D Locks (2)	

1. Carefully unpack the lamp from the carton.
2. Install turn knob (A) onto socket (Figure 1).
3. Remove finial (F) from harp (E) and save for later use.  
*Finial is shipped installed on harp.*
4. Squeeze harp (E) together while holding the locks (D) up towards the top of the harp (E) and slip into harp holder (B).
5. Allow locks (D) to slip down harp (E) and onto harp holder (B) to secure harp in place.
6. Install bulb. "C" version bulb is included.
7. Slip shade (G) onto threaded stud on top of harp (E).
8. Thread finial (F) onto threaded stud on harp (E) and tighten until snug. *Be careful not to over tighten.*




Figure 1




Figure 2

*If you need further assistance, or find that you are missing any parts, please contact the dealer from which you purchased this product. We hope you enjoy your fixture!*

\* Hubbardton Forge will not be liable for injury or damage caused by improper installation, lamping or use of this fixture.